

# NEBRASKA

## DEPT. OF WATER, ENERGY, AND ENVIRONMENT

*This guidance document is advisory in nature but is binding on an agency until amended by such agency. A guidance document does not include internal procedural documents that only affect the internal operations of the agency and does not impose additional requirements or penalties on regulated parties or include confidential information or rules and regulations made in accordance with the Administrative Procedure Act. If you believe that this guidance document imposes additional requirements or penalties on regulated parties, you may request a review of the document.*

05-164

June 2026

## Potential to Emit and No Permit Required

“Potential To Emit” or PTE is the basis for determining if you need a permit. PTE is defined at 40 CFR § 51.165(a)(1)(iii) and incorporated into Nebraska Administrative Code Title 129 – Nebraska Air Quality Regulations, Chapter 1, Section 002.76. To determine whether or not a source needs an air quality permit, you must calculate PTE and then compare the PTE to the air quality permit thresholds. The Construction Permit and Operating Permit guidance documents explain these permitting programs and permit thresholds.

A confirmation from the Nebraska Department of Water, Energy, and Environment (DWEE) is not required if the source does not need a permit. However, if a confirmation is requested, it is commonly referred to as a “No Permit Required” determination or NPR. The following explains how to calculate PTE and the records a source needs in order to demonstrate that a permit is not required.

### Calculating Potential to Emit (PTE)

PTE is calculated with the assumption that the source is operated continuously for one year (24 hours a day, 365 days a year or 8,760 hours a year). The PTE must be calculated separately for each pollutant.

The PTE calculation also assumes the emission unit(s) is uncontrolled. However, the PTE can include reductions for control equipment or other process limitations if those are included in a federally enforceable permit or required by an applicable federal standard. For instance, if your facility has an existing air quality construction permit that limits the amount of material it can process per hour, that can be taken into consideration in your PTE calculation.

Additionally, you can take into consideration certain process limitations or bottlenecks when calculating your PTE. A bottleneck is an activity or process that restricts the capacity of other operations. For example, consider a grain elevator with a dryer that has a capacity of 45,000 bushels per hour (bu/hr). The facility has one conveyor that feeds grain to the dryer. The conveyor has a capacity of 30,000 bu/hr. Because the conveyor physically limits the amount of grain that can be dried, it is a bottleneck and 30,000 bu/hr can be used to calculate the PTE for the dryer.

#### Potential To Emit Example:

The emission unit is a 50 million Btu/hour natural gas fired boiler. The following is the PTE calculation for nitrogen oxides (NO<sub>x</sub>).

Heating value of natural gas = 1,020 Btu/cubic foot

Annual operating hours = (365 days/year) x (24 hours/day) = 8,760 hours/year

Hourly maximum fuel use =  $\frac{50 \text{ million Btu/hr}}{1,020 \text{ Btu/ft}^3} = 49,020 \text{ cubic feet/hr}$

NO<sub>x</sub> emission factor from AP-42 = 100 pounds of NO<sub>x</sub> emitted per million ft<sup>3</sup> of natural gas burned

8760 hr/yr x 49,020 ft<sup>3</sup> natural gas/hr = 429.41 million ft<sup>3</sup> natural gas/year

429.41 million ft<sup>3</sup> natural gas/yr x 100 pounds NO<sub>x</sub>/ million ft<sup>3</sup> natural gas = 42,941 pounds of NO<sub>x</sub> per year

42,941 pounds/yr ÷ 2,000 pounds/ton = 21.47 tons/year

## Records

Some might assume that confirmation (commonly referred to as a “No Permit Required Determination” or NPR) from DWEE is needed to establish that a permit is not required. However, sources do not need an NPR determination from the Department if they are able to document and provide appropriate information to a Department representative, if requested, to support a claim that an air quality permit is not required. To demonstrate you don’t need a permit, you should be able to provide the PTE calculation and any supporting documentation used in the calculation.

Document the emission factors used in your PTE calculation and the source of the emission factors. Emission factors may originate from continuous emissions monitor data, stack test data, material balance equations, industry/trade organizations, and Environmental Protection Agency (EPA) documents. Use the emission factor that best represents your facility. For example, if you have source-specific stack-testing data for your facility, you should use that information to calculate your PTE because it is the most accurate information you have. Emission factors can also be found in EPA’s “AP-42, Compilation of Air Pollutant Emission Factors” if you don’t have facility-specific information. AP-42 and other emission factor resources can be found on EPA’s Clearinghouse for Inventories and Emissions Factors (CHIEF) website at <https://www.epa.gov/chief>.

You must also document the emission unit(s) design capacity. Manufacturer’s data can be used when the nameplate capacity is used in the PTE calculation. Provide documentation if you utilized any bottlenecks, permit limitations, or control equipment in your calculation and be able to explain how and why those were used in the PTE calculation. For instance, if a permit limitation was used, have a copy of the permit available.

Be sure your calculation documentation includes the appropriate units (i.e. pounds/hour, Btu/hour, etc.). It is also recommended that you document the date that the PTE was calculated.

In addition to keeping this documentation available at the facility, we encourage you to submit a letter to the DWEE Air Quality Program explaining your project and providing your emission calculations that support your determination. This will provide our staff with the most current information about your facility. The information will be entered in DWEE’s public record filing system. If your facility is inspected, this information will help the inspector better prepare and likely result in a more expedited and efficient visit.

If you have questions, submit your question via e-mail to [DWEE.AirQuality@nebraska.gov](mailto:DWEE.AirQuality@nebraska.gov) or by mail at 245 Fallbrook Blvd., Suite 100, Lincoln, NE 68521.